


Pedal Bag by Myers Design Studio



Cut a 22" by 13 1/2" of fleece fabric. Cut 2 slits for the cord to fit through about 3/4". Leave about 1" of fabric in between and 1/2 from the top of the bag.

Fold in half and then stitch 1/4" to 1/2" up the two outer sides leaving the top of the bag open.

Fold 1 1/2" down on wrong side of fabric and then stitch 1/4 to 1/2" from the edge. Leave a 1 1/2" opening so a cord can be placed inside the channel. Fish the cord through the 2 slits in the front with a safety pin.

When the cord is pulled through, tie the ends of the cord together.

